

FITTING INSTRUCTIONS

Mini bonnet release kit

Partnumber: 135.749

The cable bracket fits universally and will replace the original bracket as they are welded in on the latest Mini's. The tag points to the heater and is used on later cars to hold a relay, and the single bolthole faces the front. You must fit this bracket about 3" back from the lower padded rail of the parcel shelf and 5-6" from the RH door seal.

Be sure that there is metal under the parcel shelf where you will drill the holes for the cable bracket.

Run the cable through the bulkhead and look for the most common way, along the inner wing down to the bonnet support panel. Use cable clips to keep the cable in place.

The most common way is through the bulkhead, go left just above the crossmember that supports the master cylinder. Push the cable down under the rear of the parcel tray to the fitting bracket. Carefully drill a hole for the cable, the grommet for the bulkhead hole is on the cable.