FITTING INSTRUCTIONS Jaguar E-type compact alternator kit

Partnumber: 082.309



These units are supplied with a round

3 pin connector and short loom for ease of fitting, Wire as follows:

TERMINAL A: (red wire on loom) to dashboard warning light

TERMINAL B: (green wire on loom) to switched ignition live TERMINAL C: (blue wire on loom) to +VE side of battery.

Please note: this is the battery sensing wire and if not connected,

the warning light will not operate and

the unit will continuously operate at maximum output.

TERMINAL D: to battery main feed

To mount the Alternator:

Disconnect the battery and remove the control box

Attach together the 2 brown/white wires and the big brown/yellow wire

Attach together the brown/green wire and the small brown/yellow wire

Remove the dynamo and mount the alternator

Attach the big brown/yellow wire to the "D" battery terminal (see diaghram)

Attach the little brown/green wire to the "A" warning light (see diaghram)

Add a wire to connect the "B" ignition terminal to the contact (green or white wire) (see diaghram)

Add a wire to connect the "C" battery sensing to the battery terminal (starter switch)

Reconnect the battery negative earthed



