

# FITTING INSTRUCTIONS

## Instructions 081.510 AH 100-6 & 3000 ignition wire set

**Partnumber: 081.791**

Individual leads must be cut to length to suit early or late applications.

The lengths listed below are as per specification listed in the Austin-Healey Factory Service Parts List.

Since many engines and / or distributors may have been changed, it may be desirable to use the alternative specification lengths on some applications.

Please check carefully before cutting.

IGNITION WIRE LENGTHS		
	100-6 & 300 ( except BJ8 )	BJ8 ( 3000MKIII )
Coil to distributor	11" ( 27.94 cm )	9" ( 22.86 cm )
No. 1 Plug	13.5" ( 34.29 cm )	10" ( 25.4 cm )
No. 2 Plug	12" ( 30.48 cm )	9" ( 22.86 cm )
No. 3 Plug	9" ( 22.86 cm )	5.5" ( 13.97 cm )
No. 4 Plug	11" ( 27.94 cm )	9" ( 22.86 cm )
No. 5 Plug	11.5" ( 29.21 cm )	11" ( 27.94 cm )
No. 6 Plug	16" ( 40.64 cm )	15.5" ( 39.37 cm )