

# FITTING INSTRUCTIONS

## Silver alloy wheel 10"x 5"

**Partnumber: 046.070**



### **Before mounting :**

Ensure the wheels are approved for your car and that the wheels fit both the front and rear of the car without fouling the suspension, bodywork or steering. Also ensure the correct bolts/nuts are used and dimensions of the tyres are correct for the wheels.

### **Mounting :**

Clean any dirt or rust away from the mounting surfaces of both the wheels and the car. The centre holes surface should be covered with a thin layer of heat resitant grease in order to make later removal easier. Install the wheel bolt/nuts with a torque value of 35-45 (ft/lbs) and we recommend that the torque is rechecked after the first 80 kilometers. Also check the wheel nuts at frequent intervals.

### **Maintenance cleaning :**

Keep your wheels clean, wash them regularly especially when storing. Use the same detergents and wax for the wheels as for the carbody. Do not use acid based cleaners or any aggressive compounds that might damage the wheels. Any defects, for example scratches, in the wheel finish should be repaired in a similar way to the car body work. Primers with pigments containing iron or lead should be avoided. Repairs such as alignment, welding ...should be avoided with alloy wheels. We recommend to use Greenstuff brakepads, especially for diamond cut rims. Greenstuff pads produce less brake dust and due to this the longevity of the appearance of your wheels increase.